B B PatientBloodManagement









Patient Blood Management - what's it all about?

Patient Blood Management (PBM) is a multi-faceted and interdisciplinary treatment concept for improving patient care. The aim is to handle the patient's blood with the greatest possible care, so that the patient's exposure to allogeneic blood or allogeneic blood products in the event of anemia is kept as low as possible. This should reduce the development of hospital-acquired anemia to a minimum or completely prevent it. 1,2,3

The PBM concept is based on three key elements:

- 1. Diagnosis and therapy of pre-operative anemia
- 2. Reduction of laboratory diagnostic and interventional blood loss
- 3. Rational use of erythrocyte concentration and utilization of individual anemia tolerance

Laboratory diagnostic blood loss and clinical relevance

Hospital-associated anemia has an adverse effect on disease progression. Blood loss is especially high in cardio-surgical patients, patients with coagulation disorders, and in cases of long-term ventilation and multiple procedures due to the high frequency of blood collections.

Children, the elderly and patients with a low body weight are particularly affected.

The clinical relevance of diagnostic blood loss is still often underestimated.

- Seriously ill patients lose an average of 40-70 ml of blood/day^{4,5} and an average of 300-500 ml blood during a seven-day hospital stay^{6,7}
- > 50% of all intensive care patients are transfused with allogeneic blood products^{8,9}
- Diagnostic blood loss correlates with the frequency and severity of hospital-acquired anemia.¹⁰

How can laboratory diagnostic blood loss be reduced?

Laboratory diagnostic blood loss^{3,7} can be reduced by decreasing the sample volume of a blood collection tube. Today, only the smallest amount in the µl range is required to measure laboratory parameters.

S-Monovette® PBM – specially developed for reduced sample volumes

With the innovative and newly developed S-Monovette® 1.8 ml, SARSTEDT offers a blood collection tube with a blood volume more than 40% lower than traditional tubes. Despite the reduced volume, the standardized outer tube dimensions of the S-Monovette® are compatible with a range of analyzers.

- 1. Journal Klinikarzt Medizin im Krankenhaus 44. Jahrgang 3/2015: Patient Blood Management, Georg Thieme Verlag
- 2. KVH aktuell Jahrg. 20, Nr. 3 | September 2015: Kapitel ANÄMIE-SPECIAL Prof. Dr. med. P. Meybohm Transfusionsmedizin: Richtig handeln bei präoperativer Anämie I-XII
- 3. Patient Blood Management Braun-Scharm und Kollegen, Kapitel 4 Gombotz , Thieme Verlag 1. Auflage 2013
- 4. Corwin, et al. The CRIT study: anemia and blood transfusion in the critically ill: current clinical practice in the United States. Crit Care Med 32:39-52, 2004.
- 5. Vincent et al. Anemia and blood transfusion in critically ill patients. JAMA 2002, 288: 1499-1507.
- 6. Salisbury, et al. Diagnostic blood loss from phlebotomy and hospital-acquired anemia during acute myocardial infarction. Arch Intern Med. Vol 171 (no. 18), Oct 10, 2011.
- 7. Steiner et al Anämie auf einer Intensivstation. Blutentnahmen und Hämoglobinverlauf. Gemeinsame Jahrestagung der Schweizerischen Gesellschaften für Kardiologie, für Pneumologie, für Thoraxchirurgie, und Intensivmedizin Juni 2006
- 8. Corwin, et al. RBC transfusion in the ICU: is there a reason? Chest 108:767-771, 1995.
- 9. Rao, et al. Blood component use in critically ill patients. Anesthesia 57;530-551, 2002.
- 10. Becquet, et al. Respective effects of phlebotomy losses and erythropoietin treatment on the need for blood transfusion in very premature infants. BMC Pediatrics 13:176-182, 2013.



S-Monovette® with reduced sample volume – benefits for the patient

Significantly reduced laboratory diagnostic blood loss

Reduced rate of hospital-acquired anemia

Better patient outcome

Citrate





Standard





2.0 ml 1.0 ml



7.5 ml 4.0 ml





Citrate PBM


1.8 ml

Reduced

Serum Gel

Standard

Reduced



		Current sample volume		Reduced sample volume	
	Hospitalization	1 day	14 days	1 day	14 days
on	Serum/plasma	1 x 7.5 ml	14 x 7.5 ml = 105 ml	4 ml	14 x 4 ml = 56 ml
ratic	EDTA	1 x 2.7 ml	14 x 2.7 ml = 37.8 ml	1.6 ml	14 x 1.6 ml = 22.4 ml
Preparati	Citrate	1 x 3 ml	14 x 3 ml = 42 ml	1.8 ml	14 x 1.8 ml = 25.2 ml
<u> </u>	Blood gas	6 x 2 ml	14 x 12 ml = 168 ml	6 ml (6 x 1 ml)	14 x 6 ml = 84 ml
	Total	25.2 ml	352.8 ml	13.4 ml	187.6 ml

Example of a typical university clinic in Germany

Number of samples/year	Preparation	Typical sample volume	Reduced sample volume	Saved blood volume/tube	Saved blood volume/year	Saved blood volume in %
380,000	Serum	7.5 ml	4.0 ml	3.5 ml	1,330,000 ml	47%
400,000	EDTA	2.7 ml	1.6 ml	1.1 ml	440,000 ml	41%
250,000	Citrate	3.0 ml	1.8 ml	1.2 ml	300,000 ml	40%
360,000	Blood gas	2.0 ml	1.0 ml	1.0 ml	360,000 ml	50%
Total		5,400,000 ml	2,970,000 ml	6.8 ml	2,430,000 ml	Ø = 45 %
					= 2,430 liters	

In one year, 2,430 liters of blood could be saved, protecting patient's lives.

Ordering information

Preparation	Volume	Length/Ø	Order number based on BS 4851 (EU Code)		Order number based on ISO 6710 (US Code)	
Serum Gel	2.7 ml	75 x 13 mm	04.1923.001			
Serum Ger	4.0 ml		04.1925/04.1925.001			
Serum	2.7 ml	75 x 13 mm	04.1943.001	and the second	04.1943.100	
Serum	4 ml		04.1924	and the second	04.1924.100	
EDTA	1.6 ml	66 x 11 mm	05.1081/05.1081.001	and the family	05.1081.100	
EDIA	1.8 ml	65 x 13 mm	04.1951/04.1951.001	The state of the s	04.1951.100	
Citrate	1.8 ml	75 x 13 mm	04.1955/04.1955.001	The second second	04.1955.100	
Blood gas	1.0 ml	66 x 11 mm	05.1146/05.1146.020*		46.020*	

^{*}individually wrapped, sterile

SARSTEDT, Inc. 1025 St. James Church Road P.O. Box 468 Newton, NC 28658 - 0468

P.U. Box 468
Newton, NC 28658 - 0468
Toll free: +1 800 257 5101
Fax: +1 828 465 4003
customerservice.us@sarstedt.com
www.sarstedt.com

